

Shanghai Liangxin Electrical Co., Ltd.

NDM2-630 Product Specification

(IPD-ENG-DEV-T20 A1 2016-09-23)

Prepared by	<u>孙兰萍</u>	Date	2021-09-28
Reviewed by	陈新明	Date	2021-09-29
Countersigned by	胡志斌	Date	2021-09-29
		_	
		_	
		_	
		_	
Approved by	丁飞	Date	2021-09-29

Post code: 201315 Tel.: (021) 68586699 Address: No. 2000, South Shenjiang Road, Pudong New Area, Shanghai Fax: (021)23025796

Page 1of13



	Revision History						
Version	Revision Reason/Content	Implementatio n Date	Prepared by	Reviewe d by	Approve d by		
0	Newly added	5/8/2020	Wang Hu	Peng Haorang	Hu Qi		
1	Update the product appearance picture and product dimension outline drawing	30/9/2021	Sun Lanping	Chen Xinmin g	Ding Fei		

Address: No. 2000, South Shenjiang Road, Pudong New Area, Shanghai Post code: 201315 Tel.: (021) 68586699

Fax: (021)23025796 Page 2of13



1. Applicable Scope and Purpose of Circuit Breaker

The NDM2-630 molded case circuit breaker (hereinafter referred to as circuit breaker) applies to infrequent switching of circuits with the AC 50/60Hz, the working voltage of AC690V and working current of 630A as well as infrequent motor starting. With the overload, short circuit and undervoltage protection functions, the circuit breaker can protect lines and power equipment from damage.

2. Product Picture of Circuit Breaker (The picture is for reference only; the specific kind prevail)



Picture of the Product

Address: No. 2000, South Shenjiang Road, Pudong New Area, Shanghai Post code: 201315 Tel.: (021) 68586699 Fax: (021)23025796 Page 3of13



3. Specification and Model Description of Circuit Breaker

<u>ND</u> 1	<u>M</u> <u>2</u> − <u>630</u> <u>□</u> 2 3 4 5				
		6 7 8 9 10 11 12 13			
SN	SN name	NDM2			
1	Enterprise code	ND: "Nader" low-voltage apparatus			
2	Product code	M: Molded case circuit breaker (MCCB)			
3	Design SN	2			
4	Shell frame level	630			
		C: Basic type			
5	Breaking capacity level	L: Standard type			
	Breaking capacity level	M: Relatively high breaking type			
		H: High breaking type			
		No code: Direct handle-operated mode			
6	Operation mode	P: Motor-operated			
		Z: Rotary operation			
7	Number of poles	3, 4			
		0: Release (none)			
8	Release code	2: Instantaneous tripper only			
		3: Complex tripper			
9	Accessory code	See Table 1			
10	A	No code: Power distribution type			
10	Application code	2: Motor protection type			
		A: The N-pole isn't installed with an overcurrent release,			
		but always connected			
11	N-pole (neutral pole)	B: The N-pole isn't installed with an overcurrent release,			
11	type of the 4P product	but on-off with the other three poles			
		C: The N-pole is installed with an overcurrent tripper, and			
		on-off with the other three poles			
12	Rated current	See Table 2			
		No code: Normal product			
		P: Connection busbar			
		Z1: Rear-plate connection			
13	Cabling type	Z2H: Plug-in rear-plate connection			
	O 11	Z2Q: Plug-in front-plate connection			
		Z3H: Integrated plug-in rear-plate connection			
		Z3H: Integrated plug-in rear-plate connection Z3Q: Integrated plug-in front-plate connection			
		25 %. Integrated plag in front plate confidence			

Address: No. 2000, South Shenjiang Road, Pudong New Area, Shanghai Post code: 201315 Tel.: (021) 68586699

Fax: (021)23025796 Page 4of13



Table 1: Comparison Table of Accessory Code:



	Installation Model Position Single Property Page 1	NDM	2-630
Accessory \	Accessory name		4
00	N/A	1	_
10	Shunt release	•	
20	Dual-auxiliary contact	U	
21	Single auxiliary contact		
30	Under-voltage release		0
40	Shunt release, dual-auxiliary contact	•	0
41	Shunt release, single auxiliary contact	•	
50	Shunt release, under-voltage release	•	0
60	Two sets of dual-auxiliary contacts	0	
61	Two sets of single auxiliary contacts		
62	Dual-auxiliary contact, single auxiliary contact	0	
70	Under-voltage release, dual- auxiliary contact	0	0
71	Under-voltage release, single auxiliary contact		0
08	Alarm contact		
18	Shunt release, alarm contact		•
28	Dual-auxiliary contact, alarm contact	0	0
38	Under-voltage release, alarm contact	0	0
48	Shunt release, auxiliary alarm contact		•
58	Auxiliary alarm contact		
68	Dual-auxiliary contact, auxiliary alarm contact		U
78	Under-voltage release, auxiliary alarm contact		0

Address: No. 2000, South Shenjiang Road, Pudong New Area, Shanghai Post code: 201315 Tel.: (021) 68586699 Fax: (021)23025796

Page 5of13



4. Main Technical Parameters of Circuit Breaker

Table 2 Main Technical Parameters of Circuit Breaker

Model	NDM2-630						
Rated current of frame Inm (A)				630			
Rated current In (A)				40	00, 500, 0	530	
Rated insulation voltage	Ui (AC V)				1000		
Rated impulse withstand	voltage Ui	imp (V)			8000		
Rated working voltage U	e (AC V)			400/	415, 500	, 690	
Power frequency withsta	nd voltage	U (1min) (V)			3500		
Utilization category					A		
Number of poles	Number of poles			3			4
Breaking capacity level			С	L	M	Н	/
Rated limit	AC400/415V		35	50	65	100	65
short-circuit breaking	AC500V		/	/	30	/	/
capacity Icu (kA)	AC690V		/	/	20	/	/
Rated operating	AC400/4	15V	26.25	37.5	48.75	75	48.75
short-circuit breaking	AC500V	AC500V		/	30	/	/
capacity Ics (kA)	AC690V		/	/	15	/	/
Electrical life		7500					
Operating performance (times)	Mechan	Maintainable free life	10000				
	ical life	Maintainable life	20000				

Address: No. 2000, South Shenjiang Road, Pudong New Area, Shanghai Post code: 201315 Tel.: (021) 68586699

Fax: (021)23025796 Page 6of13



4.1 Selection of the circuit breaker connecting bus or cable cross-section area:

Table 3 Selection of the NDM2-630 Circuit Breaker Connecting Bus or Cable Cross-section Area

Rated current (A)	Cable section		Coppe	er bar size
Rated current (A)	Quantity	Cross-section area (mm ²)	Quantity	Cross-section area (mm²)
400	1	240	/	/
500	2	150	2	30×5
630	2	185	2	40×5

4.2 Tightening Torque of the Circuit Breaker Terminal and Mounting Screw

Table 4 Tightening Torque of the Circuit Breaker Terminal and Mounting Screw

Model	Thread diameter (mm)	Torque (N m)
NDM2-630	M12	28
NDW12-030	M6	6

4.3 Derating factor of temperature change for the circuit breaker

Table 5 Derating Factor Table of Temperature Change for the Circuit Breaker

Model	Derating factor of product temperature change							
NDM2-630	Temperat ure (°C)	40°C	45°C	50°C	55°C	60°C	65°C	70°C
NDM2-030	Derating factor	1	0.979	0.958	0.937	0.915	0.893	0.871

Note: 1) When the operating ambient temperature is below + 40°C, the product can be used normally without derating capacity.

2) The above derating factors are measured at the frame current.

4.4 High-altitude derating factor of the circuit breaker

Table 6 High-altitude Derating Factor Table of Circuit Breaker

Elevation (m)	Working current correction coefficient	Maximum working voltage (V)	Power frequency withstand voltage correction coefficient (V)	Isolation voltage correction coefficient (V)
2000	1	690	3500	1000
2500	1	690	3500	1000
3000	0.98	620	3150	900
3500	0.97	580	3000	850
4000	0.95	550	2800	810
4500	0.94	520	2650	770
5000	0.93	500	2500	730

Address: No. 2000, South Shenjiang Road, Pudong New Area, Shanghai

Fax: (021)23025796 Page 7of13

Post code: 201315 Tel.: (021) 68586699




5. Normal Working Environment of Circuit Breaker

- The altitude of the installation site doesn't exceed 2,500m. See the "High-altitude Derating" Factor Table of Circuit Breaker" for the derating factor at the altitude;
- The ambient temperature is $-35^{\circ}\text{C} \sim +70^{\circ}\text{C}$; the average within 24h shall not be more than +35°C. If the ambient temperature is higher than +40°C, the user needs to reduce the capacity. See the "Derating Factor Table of Temperature Change for the Circuit Breaker" for the derating factor;
- 3) Its relative humidity at an ambient temperature of +40°C should not exceed 50%. A higher relative humidity is allowed at a lower temperature. For example, the relative humidity at 20°C can reach 90%; for frost due to temperature change, the corresponding measures should be taken;
- The product can withstand the effects of wet air, salt mist, oil mist and mould;
- The installation category of the circuit breaker connected to the main loop is: Category III (power distribution and control level), The installation category of the circuit breaker not connected to the main loop is: Category II (load level);
- The pollution level is Level 3;
- The product should be installed in places that are free from explosive media, media corrosive to metal, insulation damaging gas, and conductive dust, which should be also avoided from snow and rain;
- In case of stricter user conditions than the above description, negotiate with the manufacturer.

Post code: 201315 Address: No. 2000, South Shenjiang Road, Pudong New Area, Shanghai Tel.: (021) 68586699



6. Short-circuit Overload Protection Characteristic Curve of Circuit Breaker




Time/Current Characteristic Curve

Address: No. 2000, South Shenjiang Road, Pudong New Area, Shanghai Post code: 201315 Tel.: (021) 68586699
Fax: (021)23025796 Page 9of13



7. Outline, Mounting Hole Dimensions and Safety Distance of Circuit Breaker

7.1 Outline and mounting hole dimensions of circuit breaker




Note: The limit deviation not indicated with the tolerance dimensions is as per GB/T 1804-c.

7.2 Safe mounting distance of circuit breaker

Table 7 Insulation Distance Mounted in the Metal Cabinet (Unit: mm)

Mounting distance	A (inlet wir cabine	e end to the t face)	В	С
Model	With a terminal cover	Without a terminal cover	(distance from side to the cabinet face)	(outlet wire end to the cabinet face)
NDM2-630	25	120	35	35



Address: No. 2000, South Shenjiang Road, Pudong New Area, Shanghai Post code: 201315 Tel.: (021) 68586699

Fax: (021)23025796 Page 10of13

Table 8 Minimum Center Distance between Rowed Circuit Breakers (Unit: mm)

Model	Width of ci	ircuit breaker	I Center dista	ince
Model	3 poles	4 poles	3 poles	4 poles
NDM2-630	182	240	222	280

Note: Check the connected busbar or cable during rowing or stacking of the circuit breaker to ensure that the air insulation distance won't be reduced.




Table 9 Minimum Distance between Stacked Circuit Breakers (Unit: mm)

Model	H (distance of circuit bro	distance of circuit breaker from bottom)		
Model	With a terminal cover	Without a terminal cover		
NDM2-630	155	155		

Note: 1. Bare cable connection


- 2. Cable insulating connection
- 3. Connection without insulation

Requirements: Check whether the terminal cover or phase partition is assembled properly before products are energized.

Address: No. 2000, South Shenjiang Road, Pudong New Area, Shanghai Post code: 201315 Tel.: (021) 68586699

Fax: (021)23025796 Page 11of13







8. Installation Direction of Circuit Breaker

For vertical installation of the product, the gradient between the installation surface and the vertical plane is no more than $\pm 22.5^{\circ}$.

Horizontal installation of the product.





Vertical Installation

Horizontal Installation

9. Packaging and Storage of Circuit Breaker

Minimum packaging quantity: 1 piece/box. The packaged products should be stored in a warehouse with the air ventilation and the relative humidity no more than 80% when the ambient temperature is -40°C~+75 °C. No acidic alkaline or other corrosive gas exists in the ambient air in the warehouse. Under the conditions above, the storage period shall be no more than three years since the manufacturing date.

Post code: 201315 Address: No. 2000, South Shenjiang Road, Pudong New Area, Shanghai Fax: (021)23025796 Page 12of13

Tel.: (021) 68586699



10. Installation Direction of Circuit Breaker

SN	Name	Specification	3P Quantity/Set	4P Quantity/Set
1	Cross small pan-head screw	M6×75	4	6
2	Hexagon nut	M6	4	6
3	Spring washer	6	4	6
4	Plain washer	6	8	12
5	Plug		6	8
6	Phase partition		4	6

11. Circuit Breaker Notes

- Various characteristics and accessories of the circuit breaker are set in the factory. The circuit breaker, tripping unit or other accessories can only be adjusted, installed and maintained by the trained or qualified professionals according to the parameter requirements of the line design;
- 2) Ensure that the power supply is off before installing or removing any device;
- 3) The circuit breaker handle can be located in three positions, indicating three states: on, off and free tripping. When the handle is in the free tripping position, pull the handle in the off direction when the circuit breaker is connected and on.

Address: No. 2000, South Shenjiang Road, Pudong New Area, Shanghai Post code: 201315 Tel.: (021) 68586699

Fax: (021)23025796 Page 13of13